

Powerdot MICRO

□ 935-PM30W

■ 935-PM30



CONTENT:



x1

x1

x1


- 1** DRILL
Drill a hole in the table/furniture/etc.




- 2** PLUG IN
Plug the Micro USB cable to the bottom of the Powerdot MICRO.



- 3** INSERT
Insert the Powerdot MICRO into the hole and feed the power plug through the plastic fastening nut.



- 4** TURN NUT CLOCKWISE
Turn the plastic fastening nut as far up the thread as possible.



- 5** CONNECT USB TO ADAPTER
Connect the USB A port to the schuko adapter.



- 6** PROVIDE WITH POWER
Lastly, plug the Schuko plug into the intended electrical socket.



- 2 USB charger ports (5V, 2A)

- 1.5 meter cable: USB A to USB Micro

- 1 USB A to Schuko adapter